

### Leisurecraft Bed Assembly Instructions



### **Requirements:**

2 People (recommended)
Tape Measure
Cordless Drill
Robertson Drill Bit
34"(19mm) Nut Driver Bit



# Leisurecraft Bed Assembly Instructions



To start the assembly of your Leisurecraft bed, locate the headboard and footboard.



Insert the threaded lag bolts into the holes on each of the posts.



Tighten up the lag bolts until they are about halfway into the post. (top bolt in picture)



Manufactured by:

Starting on one side of the bed, place the bracket on the side rails over the threaded lag bolts.

The slat supports are to face inwards.

Snug up the bolts but do not tighten completely.

Repeat on the opposite side of the bed.



# Leisurecraft Bed Assembly Instructions



Un-roll the slat roll onto the side rail supports with the straps up.

At this point, if the slat rolls are not close to the inside edge of the supports, you may need to use a ratchet strap to pull the side rails in.



Secure the slat roll with the provided 2" (51mm) screws in the pre-drilled holes in the middle and ends on both sides.

Tighten up lag bolts completely.

#### **Congratulations! Your Log Bed is now assembled!**

\* Check that all hardware is properly secured twice a year

Manufactured by:

