

Leisurecraft BunkBed Assembly Instructions





Inventory:

2 Bunk Bed End Assemblies 4½-log Bed Rails 2 Top-bunk Safety Rails 2 Bed Slat Rolls Hardware bag with Instructions.

2-Side Extensions (Twin/Double or Twin/Queen only.)

Requirements:

2 People (recommended)
Tape Measure
Cordless Drill
Robertson Drill Bit
3/4"(19mm) Nut Driver Bit

Manufactured by:



Leisurecraft BunkBed Assembly Instructions



To start the assembly of your Leisurecraft bunkbed, locate the 2 bunk ends.



Twin/Double or Twin/Queen Bunkbed:

(if you have not purchased a twin/double or twin/queen bunkbed, skip this and the next step.)

If you have purchased either the twin/double or the twin/queen bunk bed you will need to insert the bottom extensions into the bunk posts with the predrilled holes facing each other.

Secure the joints from the underside with the provided 2 $\frac{1}{2}$ " (64mm) screws. (1 per tenon)



Manufactured by:



Leisurecraft BunkBed Assembly Instructions



Insert the threaded lag bolts into the holes on each of the posts. (top & bottom)



Tighten up the lag bolts until they are about halfway into the post. (top bolt in picture)



Insert a safety rail in place in the top bunk.

Use a mallet to drive tenons of the safety rails into the mortise holes all the way by hitting the posts inward.

Repeat for opposite side.

(No glue or fastening hardware required).

Manufactured by:



Leisurecraft BunkBed Assembly Instructions



Starting at the top on one side of the bed, place the bracket on the side rails over the threaded lag bolts.

The slat supports are to face inwards.

Snug up the bolts but do not tighten completely.

Repeat on the opposite side of the bed.

Repeat for bottom bed side rails.



Un-roll the slat roll onto the side rail supports of the top bunk with the straps up.

At this point, if the slat rolls are not close to the inside edge of the supports, you may need to use a ratchet strap to pull the side rails in.



Secure the slat rolls with the provided 2" (51mm) screws in the pre-drilled holes in the middle and ends on both sides.

Repeat for the slat rolls on the bottom bed.

Tighten up lag bolts completely.

Congratulations! Your Log Bed is now assembled!

* Check that all hardware is properly secured twice a year

Manufactured by:



ः।: 888-923-9813 | info@leisurecraft.com| web: www.leisurecraft.com