

LS470/LS472


4' x 7' Indoor Cabin Sauna



LS470/LS472

4' x 7' Indoor Cabin Sauna



IC47B - 2 Tier Back Wall Bench



LS470/LS472

4' x 7' Indoor Cabin Sauna



IC47L - 2 Tier Back Wall Bench & Single Tier Bench on Left Side



LS470/LS472

4' x 7' Indoor Cabin Sauna


IC47R - 2 Tier Back Wall Bench & Single Tier Bench on Right Side



LS470/LS472

4' x 7' Indoor Cabin Sauna



IC47BS - Single Tier Back Wall Bench



LS470/LS472

4' x 7' Indoor Cabin Sauna

IC47S - Single Tier Side Wall Benches



LS470/LS472

4' x 7' Indoor Cabin Sauna

Front Wall Options



C7DL - Door on left & no Window
Or
C7DR - Door on right & no Window



C7DLW - Door on left & Window on right
Or
C7DRW - Door on right & Window on left
(14 3/4" x 53 1/4" Window)



C7DM - Door in middle & no Window



C7DML - Door in middle & Window on left
Or
C7DMR - Door in middle & Window on right